

9. Tighten levelling screws (B) as tight as wrench will permit you.
10. Lift locking lever and swing scope to the right. Tighten screw (G) until scope will swing with some tension, then tighten lock screw (E).
11. Lock up scope and adjust locking lever in the following manner:  
Loosen lock-screw (E). While moving locking lever (H) up and down, turn adjustment screw (F) until the lever will not go all the way down on its own. Tighten locking screw (E). Double check by snapping scope in place. The locking lever should go almost all the way down and open with some resistance. You have now removed all play.
12. Boresight or Collimate scope. Windage screws (A) allow you to adjust the windage before you fine adjust in the scope. If elevation is too far off, replace elevation block with one of proper height as covered in paragraph 6.
13. To get best results, check the following:  
Scope should swing in and out of place without any interference (stress free). Lever should snap in place. The following screws must be tight:
 

Base Screws (I)	Ring Screws
Levelling Screws (B)	Lock Screws (E)
Windage Screws (A)	

Due to manufacturing tolerances the split rings will sometimes not grip the scope tube firmly enough. In that case some metal will have to be removed where the rings are split.

### Extra care in Mounting Magnum Rifles and Heavy Scopes

On magnum rifles or heavy scopes we recommend to epoxy the front base and the front ring. Care must be taken not to get epoxy into the adjustment slot. On the most powerful magnum rifles we recommend the use of 8-40 base screws, which we can supply. Both the mount base and the holes in the receiver must be opened up for the larger screws. This will give you additional assurance of reliable performance because on E.A.W. Mounts the recoil is taken by the front ring.

#### More than one scope and a Receiver Sight can be mounted on the same bases.

When mounting more than one scope or a Receiver Sight on the same bases, some stoning could be required on the stud under the rear Elevation Block to assure uniform lock-up. A round stone of the proper diameter is needed to 'stone' the radii on the underside. (L)



Wuerzburg / Gerbrunn, Germany

Dealer:

New England Custom  
Gun Service Ltd  
info@necgts.com



www.newenglandcustomgun.com  
603-287-4836 Fax: 603-287-4832