

Grooved .22 Peep Sight Installation Instructions

Installation: Position the sight on the rear scope base or to the rear of the grooved receiver, being careful not to place it where it hinders the gun's operation, ejection or where it can be hit by the bolt handle. Tighten the two right hand clamp screws with the Allen wrench provided.

TO ADJUST THE ELEVATION: First loosen the aperture disc and turn the adjustment screw located on top of the sight body *CLOCKWISE* to *LOWER* the point of impact and *COUNTER CLOCKWISE* to *RAISE* the point of impact. 1 FULL turn of the screw = .020" of adjustment and 1/2 turn = .010" of adjustment or each graduation = .0025" of sight adjustment. Once the elevation is adjusted, tighten the aperture again.

TO ADJUST THE WINDAGE: To move the point of impact to the *RIGHT*, loosen the *left* windage screw and tighten the *right* windage screw. To move the point of impact to the *LEFT*, loosen the *right* windage screw and tighten the *left* windage screw. 1 FULL turn = .024" of adjustment and 1/2 turn = .012" of adjustment or 1/4 turn = .006" of sight adjustment.

Sight Specifications: The lowest elevation setting measures .360" from the bottom of the elevation slide to the center of the aperture opening and elevates up .125" to its highest height of .485". There is a total windage adjustment range of .080" with .040" right of center and .040" left of center.